


SUPERO[®]

SC733 CHASSIS SERIES



SC733TQ-665B


SC733T-645(B)

SC733E-465B

SC733T-465B

SC733T-450(B)

SC733T-350(B)



SC733TQ-645B

SC733i-645(B)

SC733TQ-465B

SC733i-465(B)

SC733i-450(B)

SC733i-300(B)

USER'S MANUAL

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this manual, please see our web site at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software, if any, and documentation may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any medium or machine without prior written consent.

IN NO EVENT WILL SUPERMICRO BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPERMICRO SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Super Micro's total liability for all claims will not exceed the price paid for the hardware product.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate"

WARNING: Handling of lead solder materials used in this product may expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm.

Manual Revision 1.0d
Release Date: March 3, 2010

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2010 by Super Micro Computer, Inc.
All rights reserved.
Printed in the United States of America

Preface

About This Manual

This manual is written for professional system integrators and PC technicians. It provides information for the installation and use of the SC733 chassis. Installation and maintenance should be performed by experienced technicians only.

Supermicro's SC733 chassis features a unique and highly-optimized design for dual-core Xeon platforms. The chassis is equipped with a 300W, 350W, 450W, 465W, 645W, or 665W high-efficiency power supply for superb power savings.

This document lists compatible parts available when this document was published. Always refer to the our Web site for updates on supported parts and configurations.

Manual Organization

Chapter 1: Introduction

The first chapter provides a checklist of the main components included with this chassis and describes the main features of the SC733 chassis. This chapter also includes contact information.

Chapter 2: System Safety

This chapter lists warnings, precautions, and system safety. It recommended that you thoroughly familiarize yourself installing and servicing this chassis safety precautions.

Chapter 3: System Interface

Refer to this chapter for details on the system interface, which includes the functions and information provided by the control panel on the chassis as well as other LEDs located throughout the system.

Chapter 4: Chassis Setup and Maintenance

Follow the procedures given in this chapter when installing, removing, or reconfiguring your chassis.

Appendices

This section lists compatible cables, power supply specifications, and compatible backplanes. Not all compatible backplanes are listed. Refer to our Web site for the latest compatible backplane information.

Appendix A: Chassis Cables

Appendix B: Power Supply Specifications

Appendix C: SAS-733TQ Backplane Specifications

Appendix D: SATA-733 Backplane Specifications

Table of Contents

Chapter 1 Introduction

1-1	Overview	1-1
1-2	Shipping List.....	1-1
1-3	Where to get Replacement Components.....	1-2
1-4	Contacting Supermicro.....	1-3
1-5	Returning Merchandise for Service.....	1-4

Chapter 2 System Safety

2-1	Overview	2-1
2-2	Warnings and Precautions	2-1
2-3	Electrical Safety Precautions	2-1
2-4	General Safety Precautions	2-2
2-5	System Safety	2-3

Chapter 3 System Interface

3-1	Overview	3-1
3-2	Control Panel Buttons	3-2
3-3	Control Panel LEDs	3-2

Chapter 4 Chassis Setup and Maintenance

4-1	Overview	4-1
4-2	Removing the Chassis Cover	4-2
4-3	Installing Hard Drives in the SC733i Model Chassis.....	4-3
4-4	Installing Hard Drives in the SC733T and SC733TQ	4-5
4-5	Installing a Peripheral Drive.....	4-8
4-6	Installing the Motherboard, I/O Shield and Standoffs.....	4-9
	I/O Shield	4-9
	Permanent and Optional Standoffs.....	4-10
	Motherboard Installation.....	4-11
4-7	Installing Add-on and Expansion Cards.....	4-12
	Add-on Card/Expansion Slot Setup	4-12
4-8	Removing the Fan Duct and System Fan	4-13
4-9	Checking the Server's Air Flow.....	4-14
4-10	Power Supply	4-15

Appendix A Cables, Screws, and other Accessories

Appendix B SC733 Power Supply Specifications

Appendix C SAS-733TQ Backplane Specifications

Appendix D SATA-733 Backplane Specifications

Notes

Chapter 1

Introduction

1-1 Overview

Supermicro's SC733 chassis features a unique and highly-optimized design. The chassis is equipped with high-efficiency power supply. High-performance fans provide ample optimized cooling for FB-DIMM memory modules and four hot-swappable drive bays offer maximum storage capacity.

1-2 Shipping List

Please visit the following link for the latest shipping lists and part numbers for your particular chassis model <http://www.supermicro.com/>

SC733 Chassis				
Model	CPU	HDD	I/O Slots	Power Supply
SC733TQ-665B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	665W Super Quiet
SC733TQ-645 / SC733TQ-645B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	645W
SC733T-645 / SC733T-645B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	645W
SC733i-645 / SC733i-645B	UP/DP Xeon/Opteron	4x Fixed	7x FF	645W
SC733TQ-465B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	465W Low-Noise
SC733T-465B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	465W Low-Noise
SC733i-465B	UP/DP Xeon/Opteron	4x Fixed	7x FF	465W Low-Noise
SC733E-465B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	465W Low-Noise
SC733T-450 / SC733T-450B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	450W
SC733i-450 / SC733i-450B	UP/DP Xeon/Opteron	4x Fixed	7x FF	450W

SC733 Chassis				
SC733T-350 / SC733T-350B	UP/DP Xeon/Opteron	4x SAS/SATA	7x FF	350W
SC733i-300 / SC733i-300B	UP/DP Xeon/Opteron	4x Fixed	7x FF	350W

1-3 Where to get Replacement Components

Though not frequently, you may need replacement parts for your system. To ensure the highest level of professional service and technical support, we strongly recommend purchasing exclusively from our Supermicro Authorized Distributors / System Integrators / Resellers. A list of Supermicro Authorized Distributors / System Integrators / Reseller can be found at: <http://www.supermicro.com>. Click the Where to Buy link.

1-4 Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Asia-Pacific

Address: Super Micro Computer, Inc.
4F, No. 232-1, Liancheng Rd.
Chung-Ho 235, Taipei County
Taiwan, R.O.C.

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3991

Web Site: www.supermicro.com.tw

Technical Support:

Email: support@supermicro.com.tw

Tel: 886-2-8226-1900

1-5 Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

For faster service, RMA authorizations may be requested online (<http://www.supermicro.com/support/rma/>).

Whenever possible, repack the chassis in the original Supermicro carton, using the original packaging material. If these are no longer available, be sure to pack the chassis securely, using packaging material to surround the chassis so that it does not shift within the carton and become damaged during shipping.

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

Chapter 2

System Safety

2-1 Overview

This chapter provides a quick setup checklist to get your chassis up and running. Following the steps in order given should enable you to have your chassis setup and operational within a minimal amount of time. This quick set up assumes that you are an experienced technician, familiar with common concepts and terminology.

2-2 Warnings and Precautions

You should inspect the box the chassis was shipped in and note if it was damaged in any way. If the chassis itself shows damage, file a damage claim with carrier who delivered your system.

Decide on a suitable location for the rack unit that will hold that chassis. It should be situated in a clean, dust-free area that is well ventilated. Avoid areas where heat, electrical noise and electromagnetic fields are generated.

You will also need it placed near at least one grounded power outlet. When configured, the SC733 chassis includes one power supply.

2-3 Electrical Safety Precautions

Basic electrical safety precautions should be followed to protect yourself from harm and the SC733 from damage:

- Be aware of the locations of the power on/off switch on the chassis as well as the room's emergency power-off switch, disconnection switch or electrical outlet. If an electrical accident occurs, you can then quickly remove power from the system.
- Do not work alone when working with high-voltage components.
- Power should always be disconnected from the system when removing or installing main system components, such as the serverboard, memory modules and the DVD-ROM (not necessary for hot swappable drives). When disconnecting power, you should first power down the system with the operating

system and then unplug the power cords from all the power supply modules in the system.

- When working around exposed electrical circuits, another person who is familiar with the power-off controls should be nearby to switch off the power, if necessary.
- Use only one hand when working with powered-on electrical equipment. This is to avoid making a complete circuit, which will cause electrical shock. Use extreme caution when using metal tools, which can easily damage any electrical components or circuit boards they come into contact with.
- Do not use mats designed to decrease electrostatic discharge as protection from electrical shock. Instead, use rubber mats that have been specifically designed as electrical insulators.
- The power supply power cord must include a grounding plug and must be plugged into grounded electrical outlets.
- Serverboard battery: CAUTION - There is a danger of explosion if the onboard battery is installed upside down, which will reverse its polarities. This battery must be replaced only with the same or an equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.
- Please handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Please comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly.
- DVD-ROM laser: CAUTION - this server may have come equipped with a DVD-ROM drive. To prevent direct exposure to the laser beam and hazardous radiation exposure, do not open the enclosure or use the unit in any unconventional way.

2-4 General Safety Precautions

- Keep the area around the chassis clean and free of clutter.
 - Place the chassis top cover and any system components that have been removed away from the system or on a table so that they won't accidentally be stepped on.
-

- While working on the system, do not wear loose clothing such as neckties and unbuttoned shirt sleeves, which can come into contact with electrical circuits or be pulled into a cooling fan.
- Remove any jewelry or metal objects from your body, which are excellent metal conductors that can create short circuits and harm you if they come into contact with printed circuit boards or areas where power is present.
- After accessing the inside of the system, close the system back up and secure it to the rack unit with the retention screws after ensuring that all connections have been made.

2-5 System Safety

Electrostatic discharge (ESD) is generated by two objects with different electrical charges coming into contact with each other. An electrical discharge is created to neutralize this difference, which can damage electronic components and printed circuit boards. The following measures are generally sufficient to neutralize this difference before contact is made to protect your equipment from ESD:

- Do not use mats designed to decrease electrostatic discharge as protection from electrical shock. Instead, use rubber mats that have been specifically designed as electrical insulators.
- Use a grounded wrist strap designed to prevent static discharge.
- Keep all components and printed circuit boards (PCBs) in their antistatic bags until ready for use.
- Touch a grounded metal object before removing any board from its antistatic bag.
- Do not let components or PCBs come into contact with your clothing, which may retain a charge even if you are wearing a wrist strap.
- Handle a board by its edges only; do not touch its components, peripheral chips, memory modules or contacts.
- When handling chips or modules, avoid touching their pins.
- Put the serverboard and peripherals back into their antistatic bags when not in use.

- For grounding purposes, make sure your computer chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the serverboard.

Chapter 3

System Interface

3-1 Overview

There are several LEDs on the control panel as well as others on the drive carriers to keep you constantly informed of the overall status of the system as well as the activity and health of specific components. Most SC733 models are two buttons on the chassis control panel: a reset button and a power on/off switch. This chapter explains the meanings of all LED indicators and the appropriate response you may need to take.





Figure 3-1: Front Chassis Panels

3-2 Control Panel Buttons

There are two push-buttons located on the front of the chassis. These are (in order from left to right) a reset button and a power on/off button.



- **Reset:** The reset button is used to reboot the system.



- **Power:** The main power switch is used to apply or remove power from the power supply to the server system. Turning off system power with this button removes the main power but keeps standby power supplied to the system. Therefore, you must unplug system before servicing.

3-3 Control Panel LEDs

The control panel located on the front of the SC733 chassis has five LEDs. These LEDs provide you with critical information related to different parts of the system. This section explains what each LED indicates when illuminated and any corrective action you may need to take.



- **Power:** Indicates power is being supplied to the system's power supply units. This LED should normally be illuminated when the system is operating.



- **HDD:** Indicates IDE channel activity. SAS/SATA drive, SCSI drive, and/or DVD-ROM drive activity when flashing.



- **NIC1:** Indicates network activity on GLAN1 when flashing.



- **Overheat:** Indicates an overheating or fan failure condition when flashing.

Correcting an Overheat/Fan Fail Condition

1. Check the routing of the cables and move any cables that restrict airflow.
2. Confirm that all fans are operating normally.
3. Verify that the heatsinks are installed properly.
4. If the chassis cover is not aligned correctly, the airflow may be disrupted. This leads to overheating. Confirm that the chassis cover is placed correctly.
5. This LED will remain active as long as the overheat condition exists.

Notes

Chapter 4

Chassis Setup and Maintenance

4-1 Overview

This chapter covers the steps required to install components and perform maintenance on the chassis. The only tool you will need to install components and perform maintenance is a Phillips screwdriver. Print this chapter to use as a reference while setting up your chassis.



Review the warnings and precautions listed in the manual before setting up or servicing this chassis. These include information in **Chapter 2: System Safety** and the warning/precautions listed in the setup instructions.

4-2 Removing the Chassis Cover




Figure 4-1: Removing the Chassis Cover

Removing the Chassis Cover:

1. Disconnect the chassis from any power source.
2. On the rear of the chassis, remove the two screws holding the cover in place.
3. Slide the cover back, toward the rear of the chassis
4. Lift the cover off the chassis.



Warning: Except for short periods of time, do NOT operate the server without the cover in place. The chassis cover must be in place to allow proper airflow and prevent overheating.

4-3 Installing Hard Drives in the SC733i Model Chassis




Figure 4-2: Removing the Hard Drive Module

The SC733i chassis must be powered-down before hard drives can be removed from the hard drive carriers.

Replacing Hard Drives in the SC733i Chassis

1. Disconnect the chassis from any power source.
2. Remove the two screws securing the hard drive module to the chassis.
3. Gently slide the hard drive module out of the chassis.




Figure 4-3: Removing Drives from the SC733i Hard Drive Module

4. Remove the 4 screws securing each of the hard drives.
5. Slide the drive (or dummy drive) out of the hard drive module.
6. Insert the replacement drive into the hard drive module.
7. Slide the hard drive module back into the chassis.
8. Connect the wiring to the back of the hard drive.

4-4 Installing Hard Drives in the SC733T and SC733TQ




Figure 4-4: Removing the Hard Drive Carrier from the Chassis

The SC733T and SC733TQ models feature hot-swappable hard drives, which permit the exchange of hard drives, without powering down the system

Removing Hard Drive Carriers in the SC733T and SC733TQ Chassis

1. Unlock the front bezel panel of the chassis and swing the panel to the left to open it as shown above.
2. Press the release button on the front of the drive carrier. This will cause the drive carrier handle to pop outward.
3. Using the drive carrier handle, gently pull the drive carrier out of the chassis.



Warning! Enterprise level hard disk drives are recommended for use in Supermicro chassis and servers. For information on recommended HDDs, visit the Supermicro Web site at <http://www.supermicro.com/products/nfo/files/storage/SAS-1-CompList-110909.pdf>




Figure 4-5: Chassis Drive Carrier

The drives are mounted in drive trays to simplify their installation and removal from the chassis. These trays also help promote proper airflow for the drive bays.



Warning: Except for short periods of time (swapping hard drives), do not operate the server with the chassis drive bays empty.






Figure 4-6: Removing Dummy Drive from the Drive Carrier

Installing the Hard Drive into the SC733T and SC733TQ Hard Drive Carriers

1. Remove the two screws securing the dummy drive to the drive carrier and remove the dummy drive. Place the hard drive carrier on a flat surface such as a desk, table or work bench.

**Figure 4-7: Removing Hard Drive**

2. Slide the hard drive into the carrier with the printed circuit board side facing down.
3. Carefully align the mounting holes in both the drive carrier and the hard drive.
4. Secure the hard drive to the carrier using six screws.
5. Replace the drive carrier into the chassis. Make sure to close the drive carrier handle to lock the drive carrier into place.

**Figure 4-8: Replacing Hard Drive in the SC733T and SC733TQ Chassis**

4-5 Installing a Peripheral Drive

SC733 chassis models have peripheral drive bays, in which an optional drive may be installed. This may be a CD-ROM, DVD-ROM or other device. In the unlikely event that it becomes necessary to replace a peripheral drive, use the following procedure.

Adding or Replacing a Peripheral Drive

1. Disconnect the chassis from any power source.
2. Remove the chassis cover.
3. Unplug the power and data cables from the motherboard and/or backplane.
4. **If you are adding a new peripheral drive:** Remove the mini-bezel (grate) from the drive bay. The bezel can be removed by pulling out the hard drive beneath the drive bay, then pulling the mini-bezel forward.

If you are replacing a peripheral drive: Locate the locking tab at the rear (left hand side when viewed from the front) of the drive. Push the tab toward the drive, and push the drive unit out the front of the chassis.

5. Push the new drive unit into the slot, until the tab locks into place.
6. Reconnect the data and power cables.
7. Replace the chassis cover, reconnect the power source and power up the system.




Figure 4-9: Installing the Peripheral Drive

4-6 Installing the Motherboard, I/O Shield and Standoffs




Figure 4-10: I/O Shield Placement

I/O Shield

An I/O shield holds the motherboard ports in place. Install the I/O shield before you install the motherboard. Motherboards are sold separately from the SC733 chassis and come with I/O shields specific to the motherboard.

Installing the I/O shield:

1. Review the documentation that came with your motherboard. Become familiar with component placement, requirements, and precautions.
2. Open the chassis cover.
3. With the illustrations facing the outside of the chassis, place the shield into the space provided.
4. Once installed, the motherboard will hold the I/O shield in place.

Permanent and Optional Standoffs

Standoffs prevent short circuits by securing space between the motherboard and the chassis surface. The SC733 chassis includes permanent standoffs in locations used by most motherboards. These standoffs accept the rounded Phillips head screws included in the SC733 accessories packaging.

Some motherboards require additional screws for heatsinks, general components and/or non-standard security. Optional standoffs are included to these motherboards. To use an optional standoff, you must place the hexagonal screw through the bottom the chassis and secure the screw with the hexagon nut (rounded side up). Note that motherboards are purchased separately from the chassis. Motherboard

Motherboard Installation

Installing the Motherboard:

1. Review the documentation that came with your motherboard. Become familiar with component placement, requirements, precautions, and cable connections.
2. Open the chassis cover.
3. As required by your motherboard, install standoffs in any areas that do not have a permanent standoff. To do this:
 - A. Place a hexagonal standoff screw through the bottom the chassis.
 - B. Secure the screw with the hexagon nut (rounded side up).
4. Lay the motherboard on the chassis aligning the permanent and optional standoffs
5. Secure the motherboard to the chassis using the rounded, Phillips head screws. Do not exceed nine pounds of torque when tightening the motherboard.
6. Secure the CPU(s), heatsinks, and other components to the motherboard as described in the motherboard documentation.
7. Connect the cables between the motherboard, backplane, chassis, front panel, and power supply, as needed. Also, the fans may be temporarily removed to allow access to the backplane ports.




Figure 4-11: Installing the Motherboard

4-7 Installing Add-on and Expansion Cards




Figure 4-12: Installing Add-on or Expansion Cards

Add-on Card/Expansion Slot Setup

SC733 chassis include slots for add-on cards and expansion cards. The number of cards you can use depends on your chassis model and motherboard model.

Installing Add-on and Expansion Cards

1. Disconnect the power supply, set the chassis on a flat surface, and open the chassis cover.
2. Remove the screws holding the cover in place for each add-on/expansion card slot you want to use. Keep this screw for later use.
3. Connect the add-on cards and/or expansion cards to the mother board.
4. Secure each card to the chassis using the card's L-bracket and the screw previously removed.

4-8 Removing the Fan Duct and System Fan




Figure 4-13: Replacing the Fan shroud

The fan duct concentrates airflow to maximize fan efficiency.

Removing the Fan Duct and System Fan

1. Disconnect the chassis from any power source.
2. Release the clips that secure the fan duct to the chassis. (Only the 645W and 665W versions have this type of fan).
3. Remove the screw securing the fan duct to the chassis.
4. Press down the release tabs on the fan duct as shown and pull the fan duct out from its location in the chassis.
5. Remove the four screws at the front of the fan duct that hold the fan in place. Then release the two fasteners along the side of the fan duct.
6. Separate the fan duct into two pieces remove the fan
7. Add a new fan of the same type.

4-9 Checking the Server's Air Flow

Checking the Server's Air flow

1. Make sure there are no objects to obstruct airflow in and out of the server. In addition, if you are using a front bezel, make sure the bezel's filter is replaced periodically.
2. Do not operate the server without drives or drive trays in the drive bays. Use only recommended server parts.
3. Make sure no wires or foreign objects obstruct air flow through the chassis. Pull all excess cabling out of the airflow path or use shorter cables.

The control panel LEDs inform you of system status. See "Chapter 3: System Interface" for details on the LEDs and the control panel buttons.

In most cases, the chassis power supply and fans are pre-installed. If you need to install fans continue to the Systems Fan section of this chapter. If the chassis will be installed into a rack, continue to the next chapter for rack installation instructions.

4-10 Power Supply

Depending on your chassis model the SC733 Chassis has a 300, 350, 450, 465, 645 or 665 Watt power supply. This power supply is auto-switching capable. This enables it to automatically sense and operate at a 100v to 240v input voltage. An amber light will be illuminated on the power supply when the power is off. An illuminated green light indicates that the power supply is operating.

New units can be ordered directly from Supermicro (see the contact information in the Preface).




Figure 4-14: Removing the Power Supply

Changing the Power Supply

1. Disconnect the chassis from any power source.
2. Remove the screws securing the power supply to the chassis, which are located on the rear of the chassis.
3. Pull the power supply out of the chassis.
4. Change the failed power module with the same model.
5. Push the new power supply module into the power bay until you hear a click.
6. Plug the AC power cord back into the module and power up the server.

Appendix A

Cables, Screws, and other Accessories

A-1 Overview

This appendix lists supported cables for your chassis system. It only includes the most commonly used components and configurations. For more compatible cables, refer to the manufacturer of the motherboard you are using and our Web site at: www.supermicro.com.

A-2 Cables Included with SC733 Chassis

SC733TQ-645(B), SC733i-645(B), SC733TQ-665(B)			
Part #	Type	Length	Description
CBL-0049	Cable	21"	Front panel cable, 16 pin to 16 pin
CBL-0084	Cable	6"	Split converter cable

SC733T-645(B), SC733TQ-465(B)			
Part #	Type	Length	Description
CBL-0049	Cable	21"	Front panel cable, 16 pin to 16 pin

SC733TQ-645(B), SC733TQ-465(B), SC733T-465(B), SC733i-465B, SC733T-450			
Part #	Type	Length	Description
CBL-0049L	Cable	21"	Front panel cable, 16 pin to 16 pin
CBL-0084	Cable	6"	Split converter cable

A-3 Compatible Cables

These cables are compatible with the SC733 Chassis.

Alternate SAS/SATA Cables

Some compatible motherboards have different connectors. If your motherboard has only one SAS connector that the SAS/SATA cables must share, use one of the following cables. These cables must be purchased separately.

Cable Name: SAS Cable

Quantity: 1

Part #: CBL-0175L

Alt. Name: "Big Four"

Description: This cable has one SFF-8484 (32 pin) connector on one end and 4 SAS connectors (7 pins each) at the other. This cable connects from the Host (motherboard or other controller) to the backplane SAS hard drive port.

Cable Name: SAS Cable

Quantity: 1

Part #: CBL-0116

Alt. Name: iPass or "Small Four"

Description: This cable has one ipass (SFF-8087/mini-sas) connector (36 pins) at one end and 4 SAS connectors on one end. This cable connects from the Host (motherboard or other controller) to the backplane SAS hard drive port.

Extending Power Cables

Although Supermicro chassis are designed with to be efficient and cost-effective, some compatible motherboards have power connectors located in different areas.

To use these motherboards you may have to extend the power cables to the motherboards. To do this, use the following chart as a guide.

Power Cable Extenders		
Number of Pins	Cable Part #	Length
24 pin	CBL - 0042	7.9"(20 CM)
20 pin	CBL - 0059	7.9"(20 CM)
8 pin	CBL - 0062	7.9"(20 CM)
4 pin	CBL - 0060	7.9"(20 CM)

Front Panel to the Motherboard

The SC733 chassis includes a cable to connect the chassis front panel to the motherboard. If your motherboard uses a different connector, use the following list to find a compatible cable.

Front Panel to Motherboard Cable (Ribbon Cable)		
Number of Pins (Front Panel)	Number of Pins (Motherboard)	Cable Part #
16 pin	16 pin	CBL - 0049
16 pin	20 pin	CBL - 0048
20 pin	20 pin	CBL - 0047
16 pin	various*	CBL - 0068
20 pin	various*	CBL - 0067

* Split cables: Use these cable if your motherboard requires several different connections from the front panel.

A-4 Chassis Screws

The accessory box includes all the screws needed to set up your chassis. This section lists and describes the most common screws used. Your chassis may not require all the parts listed.

M/B



Pan head
6-32 x 5 mm
[0.197]

HARD DRIVE



Flat head
6-32 x 5 mm
[0.197]

DVD-ROM, CD-ROM, and FLOPPY DRIVE



Pan head
6-32 x 5 mm
[0.197]



Flat head
6-32 x 5 mm
[0.197]



Round head
M3 x 5 mm
[0.197]



Round head
M2.6 x 5 mm
[0.197]

RAIL



Flat head
M4 x 4 mm
[0.157]



Round head
M4 x 4 mm
[0.157]



Flat head
M5 x 12 mm[0.472]
Washer for M5



M/B STANDOFFS



M/B standoff
6-32 to 6-32



M/B (CPU)
standoff
M5 to 6-32



Thumb screw
6-32 x 5 mm
[0.197]



1/U M/B standoff
6-32 x 5 mm
[0.197]



Appendix B

SC733 Power Supply Specifications

This appendix lists power supply specifications for your chassis system.

SC733						
	665W	645W	465W	450W	350W	300W
MFR Part #	PWS-665-PQ	PWS-0060	PWS-465-PQ	PWS-450(B)	PWS-0059	PWS-0041
Rated AC Voltage	100 - 240V, 50 - 60Hz, 10 - 5 Amp	100 - 240V 50 - 60Hz 11 -5 Amp	100 - 240V 50 - 60Hz 6 - 3 Amp	100 - 240V 50 - 60Hz 10 Amp	100 - 240V 50 - 60Hz 8 Amp	100 - 240V, 50 - 60Hz, 10-5 Amp
DC Out-put	N/A	5V +3.3V ≤ 160W	N/A	5V + 3.3V ≤ 160W 12V + 5V + 3.3V ≤ 430W	5V + 3.3V ≤ 166W 12V + 5V + 3.3V ≤ 334W	5V + 3.3V ≤ 180W • 12V + 5V + 3.3V ≤ 300W
+5V standby	6 Amp	4 Amp	3 Amp	2 Amp	2 Amp	2 Amp
+12V	54 Amp	46 Amp	35 Amp	30 Amp	24 Amp	15 Amp
+5V	30 Amp	30 Amp	20 Amp	26 Amp	2 Amp	30 Amp
+3.3V	24 Amp	30 Amp	15 Amp	30 Amp	25 Amp	28 Amp
-12V	0.5 Amp	0.6 Amp	0.5 Amp	1 Amp	0.5 Amp	0.8 Amp

Notes

Appendix C

SAS-733TQ Backplane Specifications

Safety Information and Technical Specifications

C-1 Safety Guidelines

To avoid personal injury and property damage, please carefully follow all the safety steps listed below when accessing your system or handling the components:

ESD Safety Guidelines

Electrostatic Discharge (ESD) can damage electronic components. To prevent damage to your system, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing a component from the antistatic bag.
- Handle the backplane by its edges only; do not touch its components, peripheral chips, memory modules or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the card and peripherals back into their antistatic bags when not in use.

General Safety Guidelines

- Always disconnect power cables before installing or removing any components from the computer, including the SAS-733TQ backplane.
- Disconnect the power cable before installing or removing any cable from the SAS-733TQ backplane.
- Make sure that the SAS-733TQ backplane is securely and properly installed on the motherboard to prevent damage to the system due to power shortage.

C-2 An Important Note to the User

All images and layouts shown in this user's guide are based upon the latest PCB Revision available at the time of publishing. The card you've received may or may not look exactly the same as the graphics shown in this manual.

C-3 Introduction to the SAS-733TQ Backplane

The SAS-733TQ backplane has been designed to utilize the most up-to-date technology available, providing your system with reliable, high-quality performance.

This manual reflects SAS-733TQ Revision 3.00, the most current release available at the time of publication. Always refer to the Supermicro Web site at www.supermicro.com for the latest updates, compatible parts and supported configurations.

Overview

The SAS-733TQ backplane is a highly efficient, highly compatible and easy to use SES-2 backplane that offers the most advanced functionality provided by the Serial Attached/Serial Link Industry in a slim package. With the built-in AMI MG 9071 chip, the SAS733TQ Backplane allows the user to configure RAID 0, RAID 1 and RAID 5, maximizing data storage capability and data transferring reliability. Additionally, the SAS733TQ supports SATA up to 3Gbps and SAS up to 3Gbps with *SES-2 (SCSI Enclosure Services-2) capabilities, providing complete Serial Attached Services and Serial Link Solutions to the market. (*Refer to the section below.)

Backplane Features

The SAS-733TQ Backplane supports the following features when it is installed on a motherboard that has an onboard SAS controller:

1. Compatible with SATA drives
2. Supporting SAS drives with a transfer rate of 3Gbps
3. Supporting I²C Interface to communicate with SAS/SATA Host Bus Adaptors (HBA)
4. Minimizing the need for cables and connectors, uncluttering server space, and providing a trouble-free installation environment for the user

5. Supporting SES-2 (SCSI Enclosure Services-2) protocol, providing the following features:

- Drive activity and drive failure indication for each drive slot
- Overheat/drive failure alarm via a buzzer* installed on the backplane
- An overheat/drive failure LED Indicator built in
- Temperature monitoring via a 2 wire (I²C) temperature sensor in the MG 9071 chip

*The buzzer sound indicates that a condition requiring immediate attention has occurred.

The buzzer alarm is triggered by the following conditions:

- Hard drive failure
- Fan failure
- System temperature over 45° Celsius.

C-4 Jumper Settings and Pin Definitions

Front Jumper/Connector Locations




Figure C-1: SAS-733TQ Front View

Front Connectors

1. JP10/JP13: Backplane main power connectors
2. JP44: I²C connector
3. JP51: Sideband header
4. SAS 0-3 Connectors: SAS#0 (J5), SAS#1 (J6), SAS#2 (J7), SAS#3 (J8),
5. JP26: Activity LED header
6. JP22: Fan header

C-5 Front Connector Pin Definitions

1. Backplane Main Power Connectors (JP10, JP13) Pin Definitions

You must use the 4-pin power connectors: JP10 and JP13 to provide adequate power to the backplane. See the table on the right for pin definitions.

Backplane Main Power
4-Pin Connector (JP10)

Pin #	Definition
1	+12V
2 and 3	Ground
4	+5V

2. Sideband Header - JP51

The sideband header is designated JP51. For SAS-II to work properly, connect an 8-pin sideband cable to JP51 as shown on the right. .

Backplane Addressing { SB5	2	1	SB6 } Controller ID
Reset { SB4	4	3	SB2 } GND
GND { SB3	6	5	SB1 } SDA
Backplane ID { SB7	8	7	SB0 } SCL
No Connection	10	9	No Connection

Sideband Pin Definitions (JP51)

3. Activity LED Header - JP26 Pin Definitions

The Activity LED header JP26 transmits signals to indicate the activity status of each SAS slot. For the Activity LED header to work properly, connect a 4-pin LED cable to Pin 1 to Pin 4 of JP26 as shown on the right. See the table on page C-6 for pin definitions.

Act In#0 {	1	6	SB6 } Controller ID
Reset { SB4	2	7	SB2 } GND
GND { SB3	3	8	SB1 } SDA
Backplane ID { SB7	4	9	SB0 } SCL
No Connection	5	X	No Connection

Note 1: "NC" = No connection

Note 2: Connect a 4-pin LED cable to Pin1 - Pin4 of JP26 only.

SAS Activity LED (JP26)

4. 3-pin Fan Header - JP22 Pin Definitions

- The 3-pin fan header is designated JP22. To prevent overheating, connect a 3-pin fan cable to JP22. See the table for pin definitions.

Note:

The fan header uses DC power.
Default: Fan disabled.

Pin Number	Definition
1	Ground (Black)
2	+12V (Red)
3	Tachometer

Caution: Fan headers are DC Powered

Fan Header Pin Definitions

5. Front Overheat/Drive Failure LED Indicators - D3/D4

Front LED	State	Specification
D3	On	Overheat, drive failure or fan failure
D4	On	Fan failure only

6. Front Panel Jumper Settings and Pin Definitions

Jumper	Description	Definition
JP18	Open (Default)	Normal
	Closed	Buzzer reset
JP26	Open (Default)	Act #0 - 3 In
JP29	Open (Default)	Normal
	Closed	MG9071 reset
JP33	1-2	I ² C controller ID: SGPIO
	2-3 (Default)	I ² C controller ID I ² C
JP34	1-2 (Default)	I ² C backplane ID: ID#0
	2-3	I ² C backplane ID: ID#1
JP40	Closed	I ² C reset: SGPIO
	Open (Default)	I ² C reset I ² C
JP42	1-2	I ² C backplane ID: SGPIO
	2-3 (Default)	I ² C backplane ID: I ² C
JP50	Open	I ² C reset SGPIO
	Short (Default)	I ² C reset I ² C (On)

7. Fan Enable/Disable

Fan	JP61	JP62
Fan Enabled	On	Pins 1-2
Fan Disabled	Off	Pins 2-3

C-6 Rear Connectors and LED Indicators

Rear connector and LED locations




Figure C-2 - Rear View

Rear Connectors

Rear Connector	Specification
J1 (Rear)	SAS#0 HDD (Connected to HDD)
J2 (Rear)	SAS#1 HDD (Connected to HDD)
J3 (Rear)	SAS#2 HDD (Connected to HDD)
J4 (Rear)	SAS#3 HDD (Connected to HDD)

Rear Connectors and LED Indicators

Rear LED Indicators	Specification
D12 (Rear)	SAS#0 Activity LED
D13 (Rear)	SAS#1 Activity LED
D14 (Rear)	SAS#2 Activity LED
D15 (Rear)	SAS#3 Activity LED
D5 (Rear)	SAS#0 Fail LED
D6 (Rear)	SAS#1 Fail LED
D7 (Rear)	SAS#2 Fail LED
D8 (Rear)	SAS#3 Fail LED

Appendix D

SATA-733 Backplane Specifications

A-1 Overview



Important! Use extreme caution when working around the Serial ATA (SATA) backplane. Do not touch the backplane with any metal objects and make sure that no ribbon cables touch the backplane or obstruct the airflow holes in the SATA backplane. All SATA drive carriers must remain in the drive bays to promote proper airflow.

The SATA backplane supports four SATA drives. The SATA drive's LED connector on the SATA backplane is JP26. There are also two power connectors on the backplane, and both connectors should be connected. Do not cascade the SATA backplane. Refer to the following table for jumper settings.

Introduction to the SATA-733 Backplane

The SATA-733 backplane has been designed to utilize the most up-to-date technology available, providing your system with reliable, high-quality performance.

This manual reflects SATA-733 Revision 3.00, the most current release available at the time of publication. Always refer to the Supermicro Web site at www.supermicro.com for the latest updates, compatible parts and supported configurations.



Figure D-1: SATA-733 Backplane

No.	Jumper	Description	Setting
1	JP18	Buzzer Reset*	Alarm Reset Header
2	JP25	Overheat Temperature	Open: 45°C Pins 1-2: 50° C (Default) Pins 2-3: 55° C
3	JP26	SATA Drive Activity	Drive Activity
4	JP28	Fan Sense	Pins 1-2: Enable Pins 2-3: Diable (Default)

*The buzzer sound indicates that a condition requiring immediate attention has occurred.

The buzzer alarm is triggered by the following conditions:

1. Hard drive failure
2. Fan failure
3. System temperature over 45° Celsius.

Notes

Disclaimer (cont.)

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.